


Instrument Panel Console Switch Assembly (86.65.17)

Removal

- 1 . Remove the audio unit side trim panels.
Release the 4 clips.



- 2 . Remove the audio unit upper trim panel.
Release the 2 clips.



- 3 . Remove the instrument panel console switch assembly.

Remove the 2 Torx screws.
Disconnect the electrical connector.

