



Rear View Mirrors - Interior Mirror

Removal and Installation


Removal



1. If installed, remove the interior mirror upper and lower covers.
 - Release the 2 clips.




2. Vehicles with an auto-dimming interior mirror, remove the interior mirror.
 - Disconnect the electrical connector.
 - Rotate the mirror stem at its base to release from the windshield.




3. Vehicles without an auto-dimming interior mirror, remove the interior mirror.
 - Pull the mirror away from the windshield to release the clip.

Installation

1. Vehicles without an auto-dimming interior mirror, install the interior mirror.
 - Slide the mirror onto the boss from above to engage the clip.



E49730



E49731

2. Vehicles with an auto-dimming interior mirror, install the interior mirror.

- Rotate the mirror stem at its base to secure to the windshield.
- Connect the electrical connector.

3. Install the interior mirror covers.

- Secure with the clips.