



# Technical Service Bulletin

No.LS501-006

16 August 2005

<b>Subject/Concern:</b>	Range Rover Sport - Water Ingress via A-Pillar Exterior Trim or A-Pillar Trim Adrift
-------------------------	--

<b>Models:</b>		
Range Rover Sport (LS)		VIN-range: 5A900500 Onwards

**Markets:** All **Section:** 501-08

## Summary:

A customer may report a concern of the illumination of miscellaneous warning lamps and/or water in footwell.

**Cause:** Water ingress through the lower slot in the body A-pillar, where the A-pillar exterior trim lower location peg locates.

**Action:** Should a customer express concern regarding the above, refer to the Service Procedure detailed in this bulletin.

<b>Parts Required:</b>		
Description	Part Number	Quantity
Repair kit	DHB500430	1


<b>Labour Time:</b>		
Operation Description	Operation No.	Time
A-pillar water ingress	75.10.89/37	0.20 hours

<b>Repair/Claim Coding:</b>	
<b>Causal Part:</b>	A-Pillar Moulding
<b>ACES Condition Code:</b>	07
<b>Defect Code:</b>	


## Service Procedure

**NOTE:** Irrespective of which side of the vehicle the water ingress/trim adrift condition is found, to ensure a right first time repair the procedure should be applied to both sides. The repair kit includes the necessary parts to perform the procedure on both sides.

- 1 . Release the five retaining clips and remove the A-pillar molding.




2 . Remove and discard the foam washer from the lower peg.




**CAUTION:** Ensure any remaining protrusions will not contact the body A-pillar.



3 . Cut away the lower location peg from the A-pillar trim.




4 . **NOTE:** Ensure the area where the patch is to be applied is clean and dry.  
**NOTE:** Ensure the patch is evenly secured and fully adhered to the body. Secure the patch supplied in the repair kit to the body, covering the lower slot in body A-pillar.



- 5 . Remove and discard the trim retaining clips.
- 6 . Attach the new clips from the repair kit to the A-pillar exterior trim bracket.



- 7  **CAUTION:** Care must be taken not to cause damage to the clips when installing the exterior trim.

**NOTE:** Ensure that the trim is secure.

Install the A-pillar exterior trim to the body.

- 8 . Repeat the procedure for the opposite side of the vehicle. ©2005